Compaq Enhanced Color Graphics Board (000410 and 000471)

SW1 Settings (As the Only/Primary Video Display Controller Board)

1	2	3	4	Monitor Type	Power-On Mode	Mode
OFF	ON	ON	OFF	Compaq Color Compatible Enh Color Compaq Dual-Mode	80 x 25 (640 x 350)	Color
ON	ON	ON	OFF	Compaq Color Compatible Enh Color Compaq Dual-Mode	80 x 25 (640 x 200)	Color
OFF	OFF	OFF	ON	RGBI Color Compaq Dual-Mode	80 x 25 (640 x 200)	Color
ON	OFF	OFF	ON	RGBI Color Compaq Dual-Mode	40 x 25 (320 x 200)	Color
OFF	OFF	ON	OFF	Compaq Dual-Mode	80 x 25 (720 x 350)	Mono

SW1 Settings (As the Secondary Video Display Controller Board)

1	2	3	4	Monitor Type	Power-On Mode	Mode
OFF	OFF	ON	ON	Compaq Color Compatible Enh Color Compaq Dual-Mode	80 x 25 (640 x 350)	Color
ON	OFF	ON	ON	Compaq Color Compatible Enh Color Compaq Dual-Mode	80 x 25 (640 x 200)	Color
OFF	ON	ON	ON	RGBI Color Compaq Dual-Mode	80 x 25 (640 x 200)	Color
ON	ON	ON	ON	RGBI Color Compaq Dual-Mode	40 x 25 (320 x 200)	Color
OFF	ON	OFF	ON	Compaq Dual-Mode	80 x 25 (720 x 350)	Mono

SW2 Settings

1	2	3	4	5	6	Monitor Type
OFF	OFF					Compaq Color, Compatible Enhanced Color (external)
ON	OFF					RGBI Color (external)
OFF	ON					Compaq Dual-Mode (external)
ON	ON					No external (Portables)
		OFF				Compaq Dual-Mode internal (Compaq Portable, Plus, Portable 286, Portable II)
		ON				No internal (Portable III*, Portable 386*, Desktops)
			ON	OFF	ON	Reserved

* Set system board setting to monochrome mode.

SW3 Settings (000410 only)

If installed, all OFF (Reserved)

Jumper P1 (External Monitor)

Pins	Monitor Type
1-2	Compaq Color or Enhanced Color
2-3	RGBI Color or Compaq Dual Mode

Jumper JP3

Pins	Address Select
1-2	3xxh (default)
2-3	2xxh